

PROFLEX (S) AIRE PTE LTD

AUTO SHUTTER INSTALLATION DETAIL

DOC NO.: 2024-INS-035

Description

PA Access Shutter (Model: AS) is designed to be installed on the wall and prevent the backflow of air from one room to another. Besides standard constructed from aluminium, galvanised steel material is available upon request.



Installation Guideline

1. Opening Clearance

The hole opening on the wall shall be larger than the combination of the AS's neck to permit the installation of the system and the gap should be within 5mm of the overall size of the AS's neck.

2. Installation Detail

A. Countersunk Screw Mounting

After insert the AS into the opening hole, direct secure the AS with the use of an M5 countersunk screw on the frame of the AS tighten it until the surface of the AS is flush with the wall.

